

Download File PDF Ademco 5828 Installation Manual

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler



so many fake sites. this is the first one which worked! Many thanks

Honeywell

ADEMCO 5828/5828V

Wireless Bidirectional Fixed-Word Keypads

INSTALLATION AND SETUP GUIDE

GENERAL INFORMATION

The ADEMCO 5828 and 5828V are wireless, bidirectional, fixed-word keypads that may be used in conjunction with DTMF and VDTX voice transmission systems. VDTX systems require use of either a 5828 Transmitter or the 5828V Receiver. The 5828V Receiver also has a 5828V Keypad Transmitter. The 5828V Keypad Transmitter is not compatible with conventional control panels that have three-digit room numbers (e.g., VDTX123456).

- Plug programmable speed function keys
 - Roll-mount plate for easy removal of the keypad and battery replacement
 - Onboard charging circuit (AC adapter kit, ADEMCO P/N 5828V)
 - Battery powered with 3-AA batteries
- The 5828V keypad additionally provides:
- Menu Message center
 - Menu Message center
 - Menu Message LED indicator
 - Built-in microphone and speaker

NOTES

The 5828/5828V cannot be used as the primary system keypad, and must not be used to program or test any security system. All systems require a hard-wired keypad or Control Panel with a hard-wired keypad.

- If the 5828/5828V is used to initiate all system functions of a fixed keypad, the 5828/5828V can be used to initiate all system functions of a fixed keypad.



5828 Keypad with Front Cover Removed



5828V Keypad with Front Cover Removed

Operation (See NOTE below)

1. **Battery Powered Operation:** When powered by battery, the keypad activates when any key is pressed. When the keypad is powered, the keypad sends a system status request, and displays and/or announces the present time and date for the system.

2. **AC Powered Operation:** When powered by AC, the keypad remains active at all times. The display is active and the display remains on the new information.

If AC power is not, the keypad will switch to battery-powered operation and AC power is restored and a new status request is made (MUTE).

NOTE: Whether the unit is powered by battery or AC, the 5828/5828V may take up to 3 seconds to display and/or announce the current date after pressing the MUTE key.

WALL MOUNTING: Before mounting the 5828 & 5828V permanently, determine a good RF location as follows:

- If interfacing to a VDTX system, try communicating with the panel from different locations.
- If interfacing to a VDTX panel, perform a CoNo Co test from the panel. Refer to the CoNo Co test guide in the Installation and Setup Guide for the panel.

Local mounting locations in or near large metal objects, since they can decrease the transmission range or block transmission.

- Remove the mounting plate to the wall, using proper steel hardware through the air mounting hole.
- Plug the cord from the optional power pack into the keypad's DC cord connector, and secure the wires through the wire grommet on the back of the keypad.
- Position the keypad over the mounting plate and slide down, engaging the four retaining clips on the plate with the corresponding clips on the keypad.

DESKTOP MOUNTING

For full portability, the keypad may be placed in any convenient, RF suitable location and operated in its battery-powered mode, or even as AC, which is powered by the optional Power Pack (see Installation, AC, ADEMCO P/N 5828V).

BATTERY INSTALLATION OR REPLACEMENT

CAUTION: Remove the AC/DC power connector from the keypad (if applicable) before attempting to install or replace the batteries.

1. Separate the keypad from its mounting plate by adding the keypad up and away from the mounting plate.
2. Open the battery compartment door to expose the batteries.

[Download PDF version of :
Ademco 5828 Installation Manual](#)