#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they

#Diego Butler



so many fake sites. this is the first one which worked! Many thanks

Rinsing and hydrating

Step	me, the Tank needs to have at leas	Result
1	Locate the clear tubing and the barbed fitting from the Milli-Q System Accessories Bag.	picture here of these items.
2	Screw the barbed fitting onto the Q-POD Dispenser. Note: Do not use any white tape on the threads of the barbed fitting. An O-ring is located inside the Q-POD Dispenser.	picture here showing the barber fitting installed on the end of the Q-POD Dispenser.
3	Push one end of the clear tubing onto the end of the barbed fitting. Place the other end of the clear tubing into a sink.	picture here showing the clear tubing attached to the barbed fitting.
4	The Milli-Q System should be in READY Mode.	65 Ad 2007 16434 1144 - 1125 Macon TO 100 T 1 25.1°C Task 1 00.0 S
5	Push the plunger down on the Q-POD Dispenser. In a few minutes, water should dispense from the Q-POD Dispenser.	85 AM 2007 16134 House Standards St
6	Dispense water for about 10 minutes. This flushes out any trapped air in most of the Milli-Q System. This also rinses off the purification media located in the Quantum Cartridge.	PEROV 05 M 2007 16444 Standard

Download PDF version of:

Millipore Elix 3 Manual

1/1